

TECHNICAL MANUAL

OPERATION, SERVICE AND REPAIR

AIRCRAFT AND MISSILE ENGINE LIFT TRAILER

MODEL 4000A

(FSN 1730-789-1249)

(AMERICAN ELECTRONICS)

F41608-84-D-A384
(ATOS)

DISCLOSURE NOTICE - This information is furnished upon the condition that it will not be released to another nation without the specific authority of the Department of the Air Force of the United States, that it will be used for military purposes only, that individual or corporate rights originating in the information, whether patented or not, will be respected, that the recipient will report promptly to the United States, any known or suspected compromise, and that the information will be provided substantially the same degree of security afforded it by the Department of Defense of the United States. Also, regardless of any other markings on the document, it will not be downgraded or declassified without written approval of the originating United States agency.

DISTRIBUTION STATEMENT - Distribution authorized to US Government agencies and their contractors (Administrative or Operational Use) (21 March 1997) . Other requests for this document should be referred to WR-ALC/LKC, Robins AFB GA 31098. Questions concerning technical content should be referred to WR-ALC/LESGL.

WARNING - This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751 *et seq.*) or the Export Administration Act of 1979, as amended (Title 50, U.S.C., App. 2401 *et seq.*). Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

HANDLING AND DESTRUCTION NOTICE - Comply with distribution statement and destroy by any method that will prevent disclosure of the contents or reconstruction of the document.

BASIC AND ALL CHANGES HAVE MERGED TO MAKE THIS A COMPLETE PUBLICATION

LIST OF EFFECTIVE PAGES

NOTE: The portion of the text affected by the changes is indicated by a vertical line in the outer margins of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by shaded areas.

Dates of issue for original and changed pages are:

Original	0.....	5 January 1962	Change.....	9.....	15 May 1995
Change.....	1.....	30 November 1970	Change.....	10.....	30 September 1995
Change.....	2.....	1 April 1971	Change.....	11.....	15 September 1996
Change.....	3.....	1 December 1971	Change.....	12.....	21 March 1997
Change.....	4.....	15 August 1972	Change.....	13.....	1 May 2000
Change.....	5.....	1 August 1973	Change.....	14.....	31 January 2003
Change.....	6.....	1 November 1979			
Change.....	7.....	30 July 1982			
Change.....	8.....	15 October 1986			

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 40, CONSISTING OF THE FOLLOWING:

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
Title		14			
A		14			
i		8			
ii Blank.....		8			
1-1		2			
1-2 - 1-3		0			
1-4 Blank.....		0			
2-1		11			
2-2		14			
2-3		0			
2-4		5			
2-5		12			
2-6		0			
3-1 - 3-2		9			
3-2A - 3-2B		13			
3-3		8			
3-4 - 3-5		0			
3-6		8			
3-7 - 3-15		0			
3-16		13			
3-17 - 3-19		0			
3-20 - 3-21		1			
3-22		0			
3-23 - 3-24		10			

*Zero in this column indicates an original page

TABLE OF CONTENTS

Section	Page	Section	Page
I INTRODUCTION	1-1	2-17. Lubrication	2-4
1-1. General	1-1	2-19. Inspection	2-5
1-3. Purpose	1-1	2-21. Trouble Shooting	2-5
1-5. Description	1-1	2-22. Care of Trailer When Not in Use. . .	2-5
1-6. General Description	1-1		
1-9. Detailed Description	1-1	III REPAIR INSTRUCTIONS	3-1
II OPERATION AND SERVICE		3-1. Disassembly	3-1
INSTRUCTIONS	2-1	3-26. Inspection Repair and Replacement	
2-1. Preparation for use	2-1	of Parts	3-2
2-3. Operation	2-1	3-27. Fits and Clearances	3-3
2-13. Component Removal and Installation . .	2-2	3-28. Cleaning	3-3
2-15. Load Transfer	2-2	3-30. Lubrication	3-3
2-16. Towing	2-4	3-31. Reassembly	3-3
		3-34. Test after Reassembly	3-23

LIST OF ILLUSTRATIONS

Number	Title	Page	Number	Title	Page
1-1	Model 4000A Aircraft and Missile		3-9	Hydraulic Installation	3-12
	Engine Lift Trailer.	1-2	3-10	Hand Driven Reciprocating Pump	
1-2	Hydraulic Diagram	1-3/4		Assembly LH & RH.	3-14
1-3	Table of Leading Particulars	1-3/4	3-11	Selector Valve Assembly	3-15
2-1	Operation	2-3	3-12	Frame Lift Cylinder Assembly	3-16
2-2	Load Transfer	2-4	3-13	LH Linear Actuating Cylinder.	3-17
2-3	Lubrication Chart.	2-4	3-14	RH Linear Actuating Cylinder.	3-17
2-4	Inspection Table	2-5	3-15	Hydraulic Lines Support	
2-5	Trouble Shooting Chart	2-5		Cover Assembly.	3-18
3-1	Model 4000A Aircraft and Missile		3-16	Connecting Rod	3-19
	Engine Lift Trailer.	3-4	3-17	Brake Pedal Assembly	3-19
3-2	Winch Drive Assembly	3-6	3-18	Brake Assembly.	3-20
3-2A	Rubber Bumper on Tow Bar.	3-6	3-19	Chassis Assembly	3-21
3-3	Winch Assembly.	3-7	3-20	Steering Tierod Assembly	3-22
3-4	Speed Decreaser Gear Box		3-21	Main Frame Assembly	3-22
	Assembly	3-8	3-22	Table of Fits and Clearances	3-23
3-5	Frame and Transfer Rail Assembly. .	3-9	3-23	Lift Test.	3-24
3-6	Rotation Adjustment Assembly	3-10	3-24	Winch Ratio Overload	
3-7	Traverse Adjustment Assembly	3-10		Adjustment	3-24
3-8	Upper Frame Assembly.	3-11			

SECTION I

INTRODUCTION

1-1. GENERAL.

1-2. This handbook is the basic handbook of Operation, Service and Repair covering Aircraft and Missile Engine Lifting Trailer, P/N 4938001, Model 4000A, FSN 1730-789-1249 manufactured by American Electronics Incorporated, El Monte, California.

1-3. PURPOSE.

1-4. The purpose of the model 4000A Trailer is to facilitate an expedient safe method of removal, transfer and installation of heavy aircraft components and other comparable equipment.

1-5. DESCRIPTION. (See figure 1-1.)

1-6. GENERAL.

1-7. The model 4000A Trailer is a four wheel mobile, hydraulically controlled self-supporting unit. No special tools or power source is required for operation. The trailer consists essentially of a set of rails connected to an elevating main frame by a hydraulically controlled linkage system. The main frame is supported by four wheels. A towbar forward and a pintle hook aft provide means of transporting the trailers singularly or in train.

1-8. Coupling assemblies are provided at rail ends to facilitate load transference from the Model 4000A to other elements of the American Electronics ground handling system.

1-9. DETAILED DESCRIPTION. (See figure 1-1.)

1-10. CHASSIS ASSEMBLY.

1-11. The chassis assembly consists of a main frame (1) supported by hydraulically controlled wheel support arms (2), four wheels (3), and tierod assemblies (4). The hydraulically controlled wheel support arms (2) are operated by wheel lift cylinders (5). A ratchet and pawl system is provided on wheel lift cylinders to provide maximum safety at any position. The hydraulic oil reservoir (6) is located in the main frame center

section. The selector valve (7) and handpumps (8) are located in the main frame side rail. Foot brakes (9) are provided on the rear wheels. Foot assemblies (10) are provided to facilitate absolute static position during critical operations. A towbar (11) and a pintle hook (12) provide a means of transport, singularly or in train.

1-12. LIFT LINKAGE.

1-13. Lift linkage consists of four lower links (13) and four upper links (14). The four lower links are hinged to the four corners of the main frame assembly (1). The upper links (14) and lower links (13) are centrally hinged in a jack-knife position and are raised and lowered by means of frame lift cylinders (15). A ratchet and pawl system is provided on lift rams for maximum safety.

1-14. UPPER FRAME, CRADLE AND RAIL ASSEMBLY.


1-15. The forward and aft ends of the upper frame assembly (16) house the cradle assemblies (17). Each cradle assembly houses two roller assemblies (18) upon which the tube and rail assembly rolls. Traverse adjustment assembly (19) provides lateral and yaw movement of the rails and rotation adjustment assembly (20) provides rail rotation adjustment.

1-16. WINCH ASSEMBLY.

1-17. A winch assembly (21) and winch drive assembly (22) are provided to facilitate moving a load onto the trailer when the rails are in an inclined position. The winch assembly may be removed from the trailer and stored when not required for handling operations. Prior to transfer or shipment of the trailer the winch assembly will be reinstalled on the trailer from which it was removed.

1-18. HYDRAULIC SYSTEM. (See figure 1-2.)

1-19. The hydraulic system consists of four hydraulic cylinders (1) which raise and lower the upper frame assembly, four wheel lifting hydraulic cylinders (2) which raise and lower the main frame, two handpumps (3) which operate the hydraulic cylinders, by selection, made by the selector valve (4), a hydraulic reservoir (5) containing the hydraulic fluid supply, and connecting lines and fittings.



- | | | | |
|----------------------|-------------------|--------------------------|--------------------------|
| 1. Main Frame | 7. Selector Valve | 13. Lower Link | 19. Traverse Adjustment |
| 2. Wheel Support Arm | 8. Hand Pump | 14. Upper Link | 20. Rotation Adjustment |
| 3. Wheel | 9. Foot Brake | 15. Frame Lift Cylinder | 21. Winch Assembly |
| 4. Tierod | 10. Foot Assembly | 16. Upper Frame Assembly | 22. Winch Drive Assembly |
| 5. Lift Cylinder | 11. Towbar | 17. Cradle Assembly | |
| 6. Reservoir | 12. Pintle Hook | 18. Roller Assembly | |

Figure 1-1. Model 4000A, Aircraft and Missile Engine Lifting Trailer




Figure 1-2. Hydraulic Diagram

MOBILITY DATA

TYPE II MOBILITY PER MIL-M-8090

Maximum Load 8000 pounds

Towing Speed. 20 MPH Max

Tire Inflation 100 psig

Turning Radius 14 ft. Min

GENERAL

Tire Size 6.00 x 9

Trailer Weight. 2760 pounds

Hydraulic Relief Pressure Setting. .4500 psig

Clearance Radius (Turning) 20 ft.

POSITIONING DATA

Rotation ± 10 degrees

Lateral. ± 3 inches

Tilt ± 10 degrees

Yaw ± 2.25 degrees

Elevation (No Load) 31.5 to 89 inches
with spacers
24.5 to 82 inches without spacers

DIMENSIONAL DATA

Wheel Base 126 inches

Tread72 inches

Rails Center to Center48 inches

Rail Width 3.33 inches

Rail Length. 152 inches

Figure 1-3. Table of Leading Particulars

SECTION II

OPERATION AND SERVICE INSTRUCTIONS

2-1. PREPARATION FOR USE.

2-2. If trailer is crated, remove crate and prepare for use as follows:

- a. Remove sides and top of crate.
- b. Assemble the draw-bar to the draw-bar link with the attached hinge pin.
- c. Check hydraulic fluid level in reservoir, refill if necessary to a depth of 3 inches. Check fluid level with all pressure released from cylinders and lines with trailer lowered to the ground in the transport position. MIL-H-5606 is system fluid. When received from the manufacturer, the hydraulic system is filled with hydraulic preservative oil, MIL-H-6083 which is compatible with the system fluid and need not be replaced.
- d. Check all pressure lines for damage and fittings for tightness.
- e. Following operating instructions, paragraph 2-4, raise main frame from crate, release foot brakes and roll trailer clear of crate bottom.

CAUTION

If trailer has been stored for prolonged periods, conduct test procedure per paragraph 3-28.

2-3. OPERATION. (See figure 2-1.)

NOTE

If hydraulic action does not function properly, bleed system in accordance with paragraph 2-8.

2-4. RAISE MAIN FRAME.

- a. Turn selector valve (1) to "WHEEL CYLINDER" position.
- b. Close pump by-pass valve (5).
- c. Raise main frame by operating two hand pumps (3) simultaneously.

2-5. LOWER MAIN FRAME.

- a. With selector valve (1) set at "WHEEL CYLINDER" position, release the four safety Locking Pins by pulling handles (4).

NOTE

Safety pawls must be in disengaged position during entire lowering procedure. If pawls will not readily disengage, raise the main frame slightly.

- b. Lower main frame by opening by-pass valves (5). Amount valves are opened controls the

rate of descent. When desired height is obtained turn by-pass valve knobs to fully closed position.

2-6. RAISE RAILS.

NOTE

The rail position adjustment is universal and any combination of positions may be accomplished within the limits described in the Leading Particulars, Figure 1-3.

- a. Position selector valve (1) at "LIFT CYLINDER" position.
- b. Raise rails to desired position by operating two hand pumps simultaneously.

2-7. LOWER RAILS.

- a. With selector valve at "LIFT CYLINDER" position, release two safety pawls by pulling knobs (6).
- b. Lower mainframe by opening by-pass valves (5). Amount valves are opened controls the rate of descent. When desired height is obtained turn by-pass valve knobs to fully closed position.

2-8. HYDRAULIC SYSTEM BLEEDING INSTRUCTIONS. (See figure 2-1.)

WARNING

Hydraulic fluid (MIL-H-5606) is highly toxic to skin, eyes and respiratory tract. Skin and eye protection is required.

- a. To bleed upper frame lift cylinder (19):

1. Set selector valve (1) to "lift cylinder" position.
2. Close by-pass valves (5).
3. Raise rails to full height by operating hand pumps.
4. Crack line fitting at head of one cylinder.
5. Bleed until hydraulic fluid shows no bubbles. Work pump handle 3 or 4 strokes to clear lines.
6. Close line fitting.
7. Repeat for other three frame lifting cylinders.

- b. To bleed wheel lifting cylinders (2):

1. Set selector valve (1) to "wheel cylinder" position.
2. Close by-pass valves (5).

3. Raise main frame to full height by operating the hand pumps.
4. Crack bleed plug at head of one cylinder, on the side of cylinder opposite the hydraulic inlet line.

NOTE

Bleed only the two cylinders located on the trailer side opposite the hand pumps.

5. Bleed until hydraulic fluid shows no bubbles. Work pump handles 3 or 4 times to clear lines.
6. Tighten bleed plug.
 - a. Fully lower upper frame and transfer rails and lower main frame to transportation position. Refill reservoir (20) to within 1/4 inch of the bottom of the filler tube with hydraulic fluid, MIL-H-5606.

2-9. TILT RAILS.

- a. To tilt rails, the fore and aft ends shall be raised and lowered individually. Follow procedures for raising and lowering rails, paragraphs 2-6 and 2-7.

CAUTION

1. Rail angle must not exceed 10 degrees.
2. Use extreme caution while tilting rails when main frame is in low position. Aft linkage must not touch ground.
3. If aft linkage inadvertently touches ground, slowly back off forward by-pass valve until rails are level; then raise rails evenly until high enough for tilt angle.

2-10. LATERAL AND YAW. (See figure 2-1.)

- a. Lateral movement of rails is accomplished by rotation of traverse adjustment handles (7). Yaw adjustment is accomplished by individual operation of adjustment handles (8).

CAUTION

Do not force adjustment beyond initial resistance.

2-11. ROLL RAILS.

- a. Roll adjustment is accomplished by turning rotation adjustment handle (8).

2-12. LOWER FOOT ASSEMBLIES.

- a. Pull pin (9) and lower foot assembly (10) to lowest position where pin can be replaced.
- b. Follow procedure for lowering mainframe, paragraph 2-5, until foot assemblies make firm contact with floor or ground.

2-13. COMPONENT REMOVAL AND INSTALLATION. (See figure 2-1.)

2-14. Details of component removal and installation vary with each application but the following general notes shall be followed:

- a. If operation requires accuracy in positioning, stabilize trailer by lowering foot assemblies (10). If foot assemblies are not used, set foot brakes (11).
- b. When installing roller adapters (12) back of (15) until jaws (14) will straddle rail flange.

NOTE

Roller adapters (12) are accessory equipment and are mentioned in this publication for reference only.

CAUTION

Lock all roller adapters by tightening at location (15) with a 1/2 inch square socket drive before releasing components from other means of support or retaining provision.

- c. To remove component horizontally, roll component and supporting adapter assemblies into position on trailer rails with 1/2-inch socket drive at location (13).

- d. For inclined removal of component, secure to winch assembly (16) by means of adapter which installs in draw-bar tube (17).

- e. Eliminate slack from linkage by rotation of winch drive (18) and accomplish removal of component with winch.

WARNING

Make certain roller adapters are in locked position before disconnecting draw-bar or moving trailer.


- f. Before moving away with loaded trailer, observe number nameplate on component adapter and position left roller adapter with corresponding number on transfer rail to properly locate center of gravity of load on trailer.

WARNING

Center of gravity of load must not move beyond limit position indicated on rails unless rail ends are adequately supported.

2-15. LOAD TRANSFER. (See figure 2-2.)

- a. Adjust rails to a level height that squarely matches rails of receiving trailer.
- b. Secure couplings (1 and 2) with lock-pin (3).



- | | | | |
|------------------------|------------------------|--------------------|-------------------------|
| 1. Selector Valve | 6. Knob | 11. Foot Brakes | 16. Winch Assembly |
| 2. Wheel Lift Cylinder | 7. Traverse Adjustment | 12. Roller Adapter | 17. Draw-Bar Tube |
| 3. Hand Pump | 8. Rotation Adjustment | 13. Drive Location | 18. Winch Drive |
| 4. Handle | 9. Pin | 14. Jaw | 19. Upper Lift Cylinder |
| 5. By-Pass Valve | 10. Foot Assembly | 15. Drive Location | 20. Reservoir |

Figure 2-1. Operation

c. Unlock roller adapters and roll load onto receiving trailer. Stops (4) must be held down to allow passage of roller adapter.

d. Lock roller adapters after positioning center of gravity of load.

e. To disconnect trailers adjust rail height of positioning trailer until quick-release pin (3) can be removed by hand.

2-16. TOWING.

- a. Make certain roller adapters are secure.
- b. Center lateral and rotational adjustment.
- c. Lower rails until upper frame pads rest on lower frame pads.
- d. Raise main frame to maximum height.
- e. Check Leading Particulars for tire pressures and towing speeds.

2-17. LUBRICATION. (See figure 2-3.)

2-18. Lubrication and lubricants to be used at specific areas are as noted on "Lubrication Chart." (See figure 2-3). Lubrication to be accomplished once a year or more frequently if required by local conditions.




Figure 2-2. Load Transfer




Figure 2-3. Lubrication Chart

2-19. INSPECTION. (See figure 2-4.)

2-20. PRE USE INSPECTION. The inspection cited in figure 2-4 will be accomplished prior to each days use when the trailer is used to install or remove an engine.

2-21. TROUBLE SHOOTING. (See figure 2-5.)

2-22. CARE OF TRAILER WHEN NOT IN USE.

2-23. When trailer is not in use, lower to transportation position.

2-24. For prolonged periods of storage, park in comparatively dust free area and cover with tarp.

CAUTION

If trailer has been stored for prolonged periods, conduct test procedure per paragraph 3-28 prior to use.

ITEM
TIRES: for damage and pressure
WHEELS: for security
BRAKE ASSEMBLIES: for proper braking action
TOWBAR: for security and condition of hinge pin
OUTRIGGER, JACK, and FOOT ASSEMBLIES: for proper action
STEERING LINKAGE: for damage, distortion, loose connections, and excessive wear
PINTLE HOOK: for security
HYDRAULIC SYSTEM: for sufficient oil supply, damaged lines, and evidences of external leakage at cylinders, valves, and fittings
LIFT LINK ASSEMBLIES: for weldment cracks, damage, distortion, excessive wear, and security at hinge points
CYLINDER ASSEMBLIES: for proper lift action inspect for damage / leakage
RATCHET and PAWL ASSEMBLIES: for proper operation perform inspection in the following order. Operate cylinder to insure that the internal lock is ratcheting while being extended. Allow the cylinder to rest, and insure it does not retract. Open release valve to insure that the internal lock is activated and the cylinder does not retract. With release valve open, pull handle that activates the cable to release the internal lock to insure cylinder retracts. Ensure that the cable not have only tension on it when the lock is in position and that it has a little slack.
PUMP ASSEMBLIES: for equally efficient and proper operation
WINCH ASSEMBLY: for condition of-chain and security of drawbar
QUICK DISCONNECTS and PRESSURE GAUGES: for installation security and proper operation (Model 4100B trailer only)
ATTACHING HARDWARE: for condition and tightness
LUBRICATION FITTINGS: for damage and obstruction

Figure 2-4. Inspection Table

TROUBLE	PROBABLE CAUSE	REMEDY
Brake failure	Worn linings	Replace shoe and lining assemblies with new
	Brake pedal pawl or spring broken, or pawl is not engaging properly with brake sector	Replace pawl or spring with new as necessary
	Brake pedal assembly shipping on shaft	Tighten pedal assembly
	Brake shoe spring broken	Replace brake shoe spring with new
Improper Winch Action	Broken chain assembly	Repair chain
	Sheared sprocket shaft	Replace sprocket shaft with new
	Sheared pin in winch drive assembly	Replace sheared pin
	Slider comb improperly engaged	Check slider assembly for improper comb engagement or damage
Shimmy while towing	Improper gear box overload clutch action	Check clutch adjustment and adjust if necessary per Test Instructions
	Low tire	Check tire inflation
	Bent wheel	Replace wheel
	Worn or distorted steering linkage or tierods	Straighten, repair or replace distorted parts
	Loosen or worn spindle balls	Tighten or replace spindle balls and retainers
Improper lift action	Main frame out of alignment	Align or replace parts of main frame as necessary
	Insufficient hydraulic oil supply	Add hydraulic oil
	Leakage at pressure lines or fittings	Replace broken lines with new and tighten fittings
	Worn hydraulic rams or pumps	Replace with new or overhaul worn assemblies
	Dirt obstruction pumps or hydraulic lines	Clean as necessary
	Air in hydraulic lines	Bleed lines. See paragraph 8.
	Worn hinge pins, bearings and bushings	Replace excessively worn hinge pins, bearings and bushings with new.
Slow setting from elevated position with ratchet and pawl assemblies disengaged	Distorted link assembly	Straighten or replace distorted link assembly with new
	Loose attaching parts	Tighten attaching parts
With ratchet and pawl assemblies engaged	Leakage in the hydraulic system or air in the pressure lines.	Repair area of leakage. Bleed system per paragraph 8.
Improper traverse and roll action	Worn or damaged pawl	Replace pawl with new
	Broken pawl cable	Replace cable with new
	Damaged or disconnected adjustment assembly	Repair, replace or correct adjustment assembly
Side sway while towing	Obstruction in the cradle or damaged roller assembly	Locate and remove obstruction. Replace or repair roller assembly
	Bent or disconnected tie rods	Repair tie rod
	Wheels out of alignment	Check alignment of wheels and for excessive tow-in
	Shifting load	Secure load
	Bent or Loose towbar	Repair, tighten or replace towbar

Figure 2-5. Trouble Shooting (Continued)

SECTION III

REPAIR INSTRUCTIONS

3-1. **DISASSEMBLY.** (See figures 3-1 through 3-15.)

3-2. **GENERAL.**

3-3. Disassemble the trailer in the general order of index numbers assigned to the exploded view illustration, paying particular attention to the following general procedures and precautions:

WARNING

Block linkage before removing pawl and ratchet assemblies on lift link and wheel cylinder rams.

a. Removal of press-fit bushings is not required unless clearance between the bushing and mating parts is in excess of maximum clearances specified in figure 3, Table of Fits and Clearances.

3-4. **DISASSEMBLY OF TRAILER.** (See figure 3-1.)

3-5. Disassemble in the order of index numbers assigned to the exploded view illustration paying particular attention to the following:

a. Raise main frame of chassis assembly to maximum height. Lower and secure four foot assemblies (74), figure 3-13.

b. Raise upper frame assembly (47) to convenient working height.

WARNING

Make certain safety pawls are securely locked before bleeding hydraulic lines.

c. Bleed hydraulic lines by opening by-pass valves on pump assemblies.

WARNING

Securely block linkage and make certain foot assemblies are secure before removal of hydraulic rams.

d. Removal of nameplates and attaching parts, indexes (141 through 153) is not required unless nameplates are defaced beyond legibility.

3-5A. **DISASSEMBLY OF LOWER LINKS.**
(See figure 3-1.)

a. Raise upper frame assembly (47) to transportation height. Lower and secure four foot assemblies (74), figure 3-19. Raise upper frame assembly (47) and place a 1 ton jack stand underneath each corner of the channel assemblies (1), figure 3-8. Lower frame assembly (47) until the weight of the channel assemblies (1) rests on the four jack stands.

WARNING

- Hydraulic fluid is highly toxic to skin, eyes, and respiratory tract. Skin and eye protection is required.
- Make certain pressure from hydraulic system has been relieved before disconnecting hydraulic lines.

b. Remove hydraulic lines from upper lift links (74, 81, 87, 93), and lower lift links (102, 109). Disconnect hydraulic lines and cap and stow lines out of the way.

c. Starting with the rear linkage assemblies remove cotter pins (59, 68, 82, 88, 99, 106) from the following locations: (a) at mount points of lift cylinders (53) located on the lower tube assembly (94), (b) at hinge points of upper links (74, 81, 87, 93), and lower links (102, 109), and front connecting link rods (58), and (c) at mount points of lower links (102, 109).

d. Using standard shop floor jack, place jack centered under rear tube assembly (94). Raise jack until slight pressure is applied to the tube assembly (94).

e. Remove nuts (60), washers (61), and bolts (62) from rear lift cylinders (53) at mount points of tube assembly (94).

CAUTION

Support lift cylinders before removal of mount bolt. Ensure the upper lift links and lift cylinders are secured by attaching a cargo strap around both upper links and lift cylinders and braced to the channel assembly. Failure to do so may result in injury to personnel or damage to equipment.

f. Remove nuts (83), washers (84), and bolts (85) from hinge points of both upper links (87, 93), and lower links (102, 109). Lower tube assembly (94) by gradually releasing pressure from the floor jack. Remove washers (107) and pins (108) from the lower links (102, 109) and slide the lower links (102, 109) out from the trailer. Remove nuts (95), washers (96), and bolts (97, 98) and remove links (102, 109) from tube assembly (94).

NOTE

If link assemblies will not separate, recommend that assemblies be heated or baked at local machine shop.

g. Disassembly of the front lift links (74, 81, 102, 109) will be performed using procedures d, e, and f and with the exception that the link rods (58) will have to be disconnected. Installation of linkage assemblies will be in reverse order of removal.

3-6. DISASSEMBLY OF WINCH-DRIVE ASSEMBLY. (See Figure 3-2.)

a. Unless visual inspection reveals sheared pins (2, 6 and 8) or bent torque tube (5) and crank assembly (9), disassembly is not required.

3-7. DISASSEMBLY OF WINCH ASSEMBLY. (See figure 3-3.)

a. Disassembly is in order of index numbers assigned to the exploded view illustration.

3-8. DISASSEMBLY OF SPEED DECREASER GEAR BOX ASSEMBLY. (See figure 3-4.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-9. DISASSEMBLY OF TRANSFER RAIL AND FRAME ASSEMBLY. (See figure 3-5.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-10. DISASSEMBLY OF ROTATION ADJUSTMENT ASSEMBLY. (See figure 3-6.)

a. Disassemble in the order of index numbers assigned to the exploded view illustration.

3-11. DISASSEMBLY OF TRAVERSE ADJUSTMENT ASSEMBLY. (See figure 3-7.)

a. Disassemble in the order of index numbers assigned to the exploded view illustration.

3-12. DISASSEMBLY OF UPPER FRAME ASSEMBLY. (See Figure 3-8.)

a. Disassemble in the order of index numbers assigned to the exploded view illustration.

3-13. REMOVAL AND DISASSEMBLY OF HYDRAULIC INSTALLATION. (See figure 3-9.)

WARNING

1. If cylinder assemblies and safety pawls have not been removed make certain safety pawls are securely engaged with cylinder rams before bleeding pressure lines and removal of hydraulic components.

2. If cylinder assemblies and safety pawls have been removed, check security of linkage blocking installed at time of removal.

3. Under no circumstances shall any part of the hydraulic installation be removed when the trailer is under load.

a. Hydraulic installation is removed and disassembled in the order of index numbers assigned to the exploded view illustration except for the warning and following special procedures.

b. Forward and aft hydraulic groups are identical except for some left and right hand parts, therefore, duplicate index numbers have been assigned to forward and aft groups.

c. To remove selector valve (59), spring pin (56), and valve handle assembly, indexes (57) and (58) must be removed in addition to attaching screws (59).

3-14. DISASSEMBLY OF LH AND RH HAND DRIVEN RECIPROCATING PUMP ASSEMBLY. (See figure 3-10.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-15. DISASSEMBLY OF SELECTOR VALVE ASSEMBLY. (See figure 3-11.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-16. DISASSEMBLY OF UPPER FRAME LIFT CYLINDER ASSEMBLIES. (See figure 3-12.)

a. Disassemble in the order of key index numbers assigned to the exploded view illustration, noting the following:

b. Prior to removing pin (1), actuate release lever (2) to unlocked position and secure in unlocked position with approximately 3/16 inch thick spacer stock inserted between washer (4) and adjacent lock boss of cylinder and boss assembly (37).

NOTE

Do not remove shoulder screw (3), washer (4), piston (12), and compression spring (13), until locking nut (9) has been removed (refer to paragraph 3-16c).

c. After removing outer bushing (6), remove screws (19); lift assembled hydraulic lock piston components (18, 20 through 24) to unlocked position; partially withdraw ram (29) from cylinder and boss assembly (37); and remove washer (7), washer (8), and locking nut (9). Then remove shoulder screw (3) and washer (4), and remove piston (12) and compression spring (13) from cylinder ID.

d. Remove tube (16) and fitting (14). Then screw a 1-1/2 (minimum) No. 8/32 NC-2A screw into end of pin (17) within the hydraulic lock boss and remove the pin. Then remove the hydraulic lock piston components (18, 20 through 24) from the cylinder boss.

e. Remove the stop (25) and ring halves (26); and remove ram (29) from bore of cylinder and boss assembly (37), exercising care to maintain axial concentricity of ram and cylinder as the ram is withdrawn.

CAUTION

Exercise extreme care to avoid "cocking" cylinder rams; the ram piston head will cause probable serious damage to the machined cylinder ID unless axial movement of the ram is concentric within the cylinder.

3-17. DISASSEMBLY OF LH LINEAR ACTUATING CYLINDER. (See figure 3-13.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-18. DISASSEMBLY OF RH LINEAR ACTUATING CYLINDER. (See figure 3-14.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-19. DISASSEMBLY OF HYDRAULIC LINES SUPPORT COVER ASSEMBLY. (See figure 3-15.)

a. Disassemble the cover assembly in the order of index numbers assigned to the exploded view illustration.

3-20. DISASSEMBLY OF CONNECTING ROD LINK. (See figure 3-16.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-21. DISASSEMBLY OF BRAKE PEDAL ASSEMBLY. (See figure 3-17.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-22. DISASSEMBLY OF BRAKE ASSEMBLY. (See figure 3-18.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-23. DISASSEMBLY OF CHASSIS ASSEMBLY. (See figure 3-19.)

Disassembly is in the order of index numbers assigned to the exploded view illustration, paying particular attention to the following:

a. Do not remove inserts (60 and 66) unless inspection reveals necessity to replace with new, since removal will result in damage beyond repair.

b. Do not attempt disassembly of cylinders (69) since repair parts or procedures are not covered in this publication.

3-24. DISASSEMBLY OF TIEROD ASSEMBLY. (See figure 3-20.)

Disassembly is in the order of index numbers assigned to the exploded view illustration, paying particular attention to the following:

a. Do not attempt disassembly of tierod end (1).

3-25. DISASSEMBLY OF MAIN FRAME ASSEMBLY. (See figure 3-21.)

a. Disassembly is in the order of index numbers assigned to the exploded view illustration.

3-26. INSPECTION, REPAIR AND REPLACEMENT OF PARTS.

(See figure 2-4, Inspection Table, Figure 2-5, Trouble Shooting Table and Figure 3-22, Table of Fits and Clearances.)

- a. General inspection shall be in accordance with Figure 2-4, Inspection Table.
- b. Inspection for excessive wear between critical mating parts shall be in accordance with Figure 3-22, Table of Fits and Clearances.
- c. Any part distorted beyond practicable repair shall be replaced with new.
- d. If wheel bearings are worn or damaged, replace with new.
- e. If hydraulic valves, pumps and cylinders are worn, fractured, or if port threads are stripped beyond practical repair, replace with new.

- f. If threads and steering linkage are damaged or distorted beyond practical repair, replace with new.

- g. Distorted lift linkage, frame and chassis components may be straightened if adequate equipment is available, otherwise replace with new.

- h. If tilt indicator is inoperative, replace with new.

NOTE

When tilt indicator, Part No. A91005C, Figure 3-5, Index 1, is used, drill an additional hole using a 7/32-inch drill. Hole spacing will be 3-3/4-inch center to center.

i. Cross tube assembly repairs: The brackets on the forward cross tube assembly where the towbar fitting part No. 11426 is attached to the trailer may be repaired if the holes become worn and/or elongated in any direction 0.050 inch over standard diameter of 0.501 inch. Repairs shall be accomplished as follows: Ream the holes in line to a diameter of $0.549 + 0.0004$, -0.0000 and insert press fit bushing part No. NAS75-8-010 or equal. Bushings may be locally manufactured and replaced as required provided the holes do not require further dressing for bushing installation. When the holes in the cross tube brackets exceed the tolerance specified the cross tube assembly will be replaced.

j. In the event users are experiencing wear of the lunette, installation of a rubber bumper on the towing tongue is authorized as shown in figure 3-2A.

3-27. TABLE OF FITS AND CLEARANCES. (See figure 3-22, Table of Fits and Clearances.)

NOTE

If clearances between parts listed in the following table are in excess of those specified, replace one or both mating parts with new, as necessary.

3-28. CLEANING.

3-29. Clean all parts thoroughly in cleaning solvent, Specification P-D-680, Type II, paying particular attention to the following:

WARNING

- Perform all solvent cleaning operations in an approved cleaning cabinet or in a well ventilated area. Avoid prolonged breathing of vapors. Avoid eye and repeated skin contact. Keep solvents away from sparks and flames.
 - Use approved personal protective equipment (goggles/face shield) when using compressed air. Maximum allowable air pressure for cleaning operations is restricted to less than 30 psi. Provide protection from flying particles when using compressed air. Do not direct airstream towards self or other personnel.
- a. Make certain all critical mating surfaces are free of dust, corrosion and solidified oil film.
 - b. Make certain all pressure lines, valves, ports and flow passages are free of obstruction.
 - c. Make certain all threaded areas are free of grit and other foreign matter.
 - d. Dry all parts thoroughly after cleaning.

3-30. LUBRICATION OF REASSEMBLY. (See figure 2-3, Lubrication Chart.)

a. Lubricate in accordance with Lubrication Chart at each overhaul.

3-31. REASSEMBLY. (See figures 3-1 through 3-21.)

3-32. GENERAL.

3-33. Reassemble each group assembly in the reverse order of index numbers assigned to the applicable exploded view illustration, paying particular attention to the following:

a. Support lift linkage assemblies with blocks or equivalent until hydraulic installation has been installed and reservoir filled.

b. Make certain all linkage hinge points are properly aligned.

NOTE

After steering linkage and tierods have been installed, adjust front wheels to 1.5 degree toe-in. Use standard shop practice for toe-in adjustment.

c. Make certain all attaching parts are secure and accounted for.

WARNING

Hydraulic fluid (MIL-H-5606) is highly toxic to skin, eyes and respiratory tract. Skin and eye protection is required.

d. Make certain all hydraulic lines and fittings are thoroughly clean and properly mated. Prior to installation, coat all straight threads with hydraulic oil, specification MIL-H-5606 and all tapered threads with antiseize compound, specification JAN-A-669.

e. When installing hydraulic rams make certain lubrication fittings are on the bottom side.

f. Make certain all lubrication fittings (69 total) are clean and installed.

g. Lubricate trailer in accordance with figure 2-3, Lubrication Chart, after complete reassembly.

h. Adjust brakes following standard mechanical brake adjustment procedure.

i. Fill Hydraulic Reservoir with Fluid, Specification MIL-H-5606, to a depth of 3 inches.

NOTE

Reservoir must be filled with upper frame fully lowered, main frame lowered to transportation position, and the pump handles in down position.





Figure 3-1. Model 4000A, Aircraft and Missile Engine Lifting Trailer


KEY TO FIGURE 3-1

1. Winch Drive Assembly	53. Hydraulic Installation	108. Pin
2. Nut	54. Tube Assembly	109. Link
3. Bolt	55. Nut	110. Lubrication Fitting
4. Spring Pin	56. Washer	111. Bushing
5. Winch Assembly	57. Bolt	112. Bushing
6. Nut	58. Link Rod	113. Brake Pedal Assembly
7. Washer	59. Cotter Pin	114. Brake Sector
8. Bolt	60. Nut	115. Screw
9. Rail and Frame Assembly	61. Washer	116. Washer
10. Cotter Pin	62. Clevis Bolt	117. Nut
11. Nut	63. Cotter Pin	118. Washer
12. Washer	64. Nut	119. Tire
13. Screw	65. Washer	120. Tube
14. Nut	66. Bolt	121. Flap
15. Washer	67. Spacer	122. Wheel
16. Screw	68. Cotter Pin	123. Grease Cap
17. Retaining Strap	69. Nut	124. Cotter Pin
18. Bushing	70. Washer	125. Nut
19. Screw	71. Bolt	126. Washer
20. Washer	72. Lubrication Fitting	127. Bearing Outboard Cup
21. Washer	73. Bearing	128. Bearing Outboard Cone
22. Pin	74. Link RH	129. Bearing Inboard Cup
23. Bushing	75. Cotter Pin	130. Bearing Inboard Cone
24. Roller	76. Nut	131. Seal
25. Traverse Adjustment Assembly	77. Washer	132. Bolt
26. Cotter Pin	78. Bolt	133. Bolt
27. Nut	79. Lubrication Fitting	134. Hub
28. Washer	80. Bearing	135. Brake Assembly
29. Bolt	81. Link	136. Brake Assembly
30. Bushing	82. Cotter Pin	137. Nut
31. Nut	83. Nut	138. Washer
32. Winch Crank Bracket	84. Washer	139. Bolt
33. Nut	85. Bolt	140. Chassis Assembly
34. Screw	86. Lubrication Fitting	141. Operating Instructions Plate
35. Cradle Retaining Strap	87. Link	142. Lubrication Instruction Plate
36. Bolt	88. Cotter Pin	143. Instruction Load Plate
37. Washer	89. Nut	144. Instruction Plate
38. Nut	90. Washer	145. Instruction Caution Plate
39. Washer	91. Bolt	146. Tire Inflation Instruction Plate
40. Screw	92. Lubrication Fitting	147. Towing Instruction Plate
41. Traverse Adjustment Bracket	93. Link	148. Reservoir Instruction Plate
42. Nut	94. Tube Assembly	149. Instruction Winch Plate
43. Screw	95. Nut	150. Instruction Tie Down Plate
44. Cradle Support Pin	96. Washer	151. Instruction Tie Down Plate
45. Cotter Pin	97. Bolt	152. Model 4000A Instruction Plate
46. Upper Frame Cradle Assembly	98. Bolt	153. Screw
47. Upper Frame Assembly	99. Cotter Pin	154. Screw
48. Cotter Pin	100. Washer	
49. Nut	101. Pin	
50. Washer	102. Link, LH fwd, RH aft	
51. Bolt	103. Lubrication Fitting	
52. Bushing	104. Bushing	
	105. Bushing	
	106. Cotter Pin	
	107. Washer	




- | | | |
|------------------------|----------------|--------------------|
| 1. Universal Joint | 4. Bushing | 7. Universal Joint |
| 2. Spring Pin | 5. Torque Tube | 8. Spring Pin |
| 3. Torque Tube Bracket | 6. Pin | 9. Hand Crank |

Figure 3-2. Winch Drive Assembly, Part No. 104401



PART NUMBER	DESCRIPTION	UNITS PER ASSY
DLA500-85-D050	BUMPER	1
AN4015	BOLT	1
AN364C428	NUT	1

Figure 3-2A. Rubber Bumper on Tow Bar



- | | | |
|-----------------------|---------------------------|-----------------------------------|
| 1. Tube | 23. Take-Up Yoke | 45. Ratio Box Cover |
| 2. Quick-Release Pin | 24. Adjust Bolt | 46. Bolt |
| 3. Cover | 25. Nut | 47. Bolt |
| 4. Sleeve | 26. Adjust Nut | 48. Washer |
| 5. Cable | 27. Pin | 49. Spacer |
| 6. Quick-Release Pin | 28. End Sprocket | 50. Idler Bracket |
| 7. Cover | 29. Bearing | 51. Bolt |
| 8. Sleeve | 30. Nut | 52. Washer |
| 9. Cable | 31. Washer | 53. Bolt |
| 10. Quick-Release Pin | 32. Bolt | 54. Washer |
| 11. Cover | 33. Pin | 55. Washer |
| 12. Sleeve | 34. Sprocket | 56. Idler |
| 13. Cable | 35. Bearing | 57. Bearing |
| 14. Tube Assembly | 36. Roller Chain | 58. Speed Decreaser Gear Assembly |
| 15. Draw-bar Fitting | 37. Connecting Link | 59. Nut |
| 16. End Cover Plate | 38. Top Plate | 60. Washer |
| 17. Nut | 39. Screw | 61. Bolt |
| 18. Washer | 40. Slider Guide | 62. Bolt |
| 19. Clevis Bolt | 41. Guide | 63. Washer |
| 20. Bolt | 42. Comb Assembly | 64. Rail Assembly |
| 21. Washer | 43. Pivot Pin | |
| 22. Yoke Spacer | 44. Bottom Plate Assembly | |

Figure 3-3. Winch Assembly





Figure 3-4. Speed Decreaser Gear Box Assembly


KEY TO FIGURE 3-4

- | | | | |
|------------------|----------------|----------------|------------------|
| 1. Wire | 15. Lock Ring | 29. Lockwasher | 43. Ball Bearing |
| 2. Cover | 16. Lead Seal | 30. Washer | 44. Wire |
| 3. Screw | 17. Wire | 31. Spring | 45. Retainer |
| 4. Washer | 18. Name Plate | 32. Ring | 46. Screw |
| 5. Gasket | 19. Screw | 33. Snap Ring | 47. Washer |
| 6. Spacer | 20. Extension | 34. Clutch | 48. Gasket |
| 7. Snap Ring | 21. Screw | 35. Wire | 49. Spacer |
| 8. Ball Bearing | 22. Lockwasher | 36. Plate | 50. Snap Ring |
| 9. Spacer | 23. Snap Ring | 37. Screw | 51. Ball Bearing |
| 10. Gear | 24. Washer | 38. Washer | 52. Worm |
| 11. Ball Bearing | 25. Cover | 39. Disc | 53. Key |
| 12. Shaft | 26. Screw | 40. Washer | 54. Shaft |
| 13. Seal | 27. Lockwasher | 41. Spring | 55. Housing |
| 14. Insert | 28. Locknut | 42. Snap Ring | |




- | | | | |
|----------------------|----------------------|------------------------|----------------------------------|
| 1. Tilt Indicator | 11. Female Coupling | 21. Stop Spring | 31. Nut |
| 2. Nut | 12. Male Coupling | 22. Stop Bracket | 32. Washer |
| 3. Screw | 13. Nut | 23. Nut | 33. Bolt |
| 4. Nut | 14. Bolt | 24. Bolt | 34. Rotation Adjustment Assembly |
| 5. Bolt | 15. Bolt | 25. Washer | 35. Screw |
| 6. Bolt | 16. Rail Guide Clip | 26. Transfer Rail Beam | 36. Nut |
| 7. Quick-Release Pin | 17. Nut | 27. Nut | 37. Tube Assembly, Fwd |
| 8. Cover | 18. Bolt | 28. Washer | 38. Tube Assembly, Aft |
| 9. Sleeve | 19. Spring Pin | 29. Bolt | |
| 10. Cable | 20. Adapter Stop Pin | 30. Rail Spacer Block | |

Figure 3-5. Frame and Transfer Rail Assembly




- | | | | |
|---------------|------------|------------------------|----------|
| 1. Knob | 4. Bracket | 6. Bearing | 8. Screw |
| 2. Cotter Pin | 5. Nut | 7. Lubrication Fitting | 9. Tube |
| 3. Pin | | | |

Figure 3-6. Rotation Adjustment Assembly



- | | | | |
|-----------|------------|------------------------|-----------|
| 1. Knob | 4. Bolt | 7. Bushing | 10. Tube |
| 2. Nut | 5. Spacer | 8. Lubrication Fitting | 11. Screw |
| 3. Washer | 6. Eyebolt | 9. Washer | |

Figure 3-7. Traverse Adjustment Assembly



1. Channel Assembly
2. Nut

3. Bolt
4. Side Channel RH

5. Side Channel LH
6. Bracket

7. Nut
8. Screw

Figure 3-8. Upper Frame Assembly




Figure 3-9. Hydraulic Installation

KEY TO FIGURE 3-9.

1. Hose Assembly	37. Nipple	73. Cotter Pin
2. Elbow	38. Tube Assembly	74. Washer
3. Elbow	39. Nipple	75. Pin
4. Bushing	40. Relief Valve	76. Tube Assembly
5. Plug	41. Elbow	77. Tube Assembly
6. Hose Assembly	42. Tube Assembly	78. Tee
7. Tube	43. Relief Valve	79. Tee
8. Clamp	44. Nipple	80. Cap Assembly
9. Nut	45. Elbow	81. Elbow
10. Clamp	46. Tee	82. Nut
11. Screw	47. Tube Assembly	83. Gasket
12. Clamp	48. Union	84. Ring
13. Screw	49. Gasket	85. Tube Assembly
14. Washer	50. Filter	86. Union
15. Elbow	51. Gasket	87. Gasket
16. Hose Assembly	52. Nipple	88. Tee
17. Clamp	53. Pump Assembly	89. Cap Assembly
18. Screw	54. Screw	90. Gasket
19. Nipple	55. Washer	91. Ring
20. Elbow	56. Spring Pin	92. Nut
21. Bushing	57. Ball	93. Cylinder Assembly
22. Plug	58. Selector Valve Handle	94. Fitting
23. Hose Assembly	59. Selector Valve Assembly	95. Pin
24. Rubber Tube	60. Screw	96. Cotter Pin
25. Clamp	61. Stop	97. Nut
26. Nut	62. Screw	98. Washer
27. Clamp	63. Nut	99. Cotter Pin
28. Screw	64. Screw	100. Nut
29. Screw	65. Knob	101. Washer
30. Clamp	66. Guide	102. Bolt
31. Screw	67. Retaining Ring	103. Bushing
32. Washer	68. Bracket	104. Hose Assembly
33. Nipple	69. Bracket	105. Clamp
34. Tube Assembly	70. Cover Assembly	106. Elbow
35. Elbow	71. Screw	107. Bushing
36. Tube Assembly	72. Washer	





Figure 3-10. Hand Driven Reciprocating Pump Assembly L. H. & R. H.


KEY TO FIGURE 3-10.

- | | | | |
|-------------------------|---------------|---------------------|-------------|
| 1. Identification Plate | 11. Ball | 21. Ball | 31. Bushing |
| 2. Grip | 12. Plug | 22. Body | 32. Scraper |
| 3. Pin | 13. Packing | 23. Gasket | 33. Packing |
| 4. Knob | 14. Plug | 24. Set Screw | 34. Backup |
| 5. Packing | 15. Spring | 25. Ball | 35. Packing |
| 6. Stem | 16. Ball | 26. Bolt | 36. Packing |
| 7. Ball | 17. Set Screw | 27. Nut | 37. Backup |
| 8. Set Screw | 18. Spring | 28. Bolt | 38. Piston |
| 9. Ball | 19. Ball | 29. Nut | 39. Housing |
| 10. Set Screw | 20. Ring | 30. Connecting Link | 40. Handle |




- | | | | |
|--------------|--------------|-----------------|-----------------|
| 1. Nameplate | 9. Ball | 17. Bearing | 25. Shaft |
| 2. Screw | 10. Spring | 18. Plate | 26. "O" Ring |
| 3. Pin | 11. Pin | 19. "O" Ring | 27. Backup Ring |
| 4. Sleeve | 12. Body | 20. Backup Ring | 28. Shear Seal |
| 5. Disc | 13. "O" Ring | 21. "O" Ring | 29. Spring |
| 6. Screw | 14. "O" Ring | 22. Bearing | 30. Body |
| 7. Washer | 15. Pin | 23. Pin | |
| 8. Washer | 16. Rotor | 24. Rotor | |

Figure 3-11. Selector Valve Assembly




- | | | | |
|--------------|-------------|-----------------|-----------------|
| 1. Pin | 11. Washer | 21. Spring | 31. Packing |
| 2. Lever | 12. Piston | 22. Packing | 32. Backup Ring |
| 3. Screw | 13. Spring | 23. Packing | 33. Screw |
| 4. Washer | 14. Fitting | 24. Piston | 34. Washer |
| 5. Set Screw | 15. Packing | 25. Stop | 35. Bracket |
| 6. Bushing | 16. Tube | 26. Ring | 36. Plate |
| 7. Washer | 17. Pin | 27. Packing | 37. Cylinder |
| 8. Washer | 18. Screw | 28. Backup Ring | |
| 9. Nut | 19. Screw | 29. Ram | |
| 10. Washer | 20. Cover | 30. Adapter | |

Figure 3-12. Frame Lift Cylinder Assembly




- | | | | |
|---------------|-----------------|---------------|-----------------|
| 1. Pin Spring | 7. Cylinder Cap | 13. Ram Nut | 19. Backup Ring |
| 2. Lever | 8. Spring | 14. Washer | 20. Ram |
| 3. Screw | 9. Lock Piston | 15. Stop | 21. Plate |
| 4. Washer | 10. Set Screw | 16. Pipe Plug | 22. Cylinder |
| 5. Screw | 11. Bushing | 17. Ring | |
| 6. Spring | 12. Washer | 18. Packing | |

Figure 3-13. L.H. Linear Actuating Cylinder




- | | | |
|------------|--------------|-------------------------|
| 1. Screw | 5. Pipe Plug | 9. Identification Plate |
| 2. Bushing | 6. Packing | 10. Cylinder |
| 3. Spacer | 7. Packing | |
| 4. Ring | 8. Ram | |

Figure 3-14. R.H. Linear Actuating Cylinder




- | | | | |
|----------------|----------------|----------------|-------------------|
| 1. Channel | 12. Clevis | 22. Terminal | 32. Nut |
| 2. Spring | 13. Nut | 23. Terminal | 33. Screw |
| 3. Bracket | 14. Terminal | 24. Clevis | 34. Nut |
| 4. Nut | 15. Terminal | 25. Cable | 35. Washer |
| 5. Washer | 16. Clevis | 26. Cotter Pin | 36. Screw |
| 6. Screw | 17. Cable | 27. Pin | 37. Bracket |
| 7. Pulley | 18. Cotter Pin | 28. Clevis | 38. Nut |
| 8. Cotter Pin | 19. Pin | 29. Cable | 39. Release Lever |
| 9. Pin | 20. Clevis | 30. Terminal | 40. Cotter Pin |
| 10. Cotter Pin | 21. Nut | 31. Strip | 41. Pin |
| 11. Pin | | | |

Figure 3-15. Hydraulic Lines Support Cover Assembly




- | | | | |
|-------------------|-----------|-------------------------|-----------------------|
| 1. Rod End Clevis | 5. Washer | 9. Washer | 13. Rod End Connector |
| 2. Sleeve | 6. Bolt | 10. Bolt | 14. Tube |
| 3. Nut | 7. Nut | 11. Bearing | |
| 4. Washer | 8. Washer | 12. Lubrication Fitting | |

Figure 3-16. Connecting Rod



- | | | | |
|-----------|-----------|------------|-----------------------|
| 1. Nut | 5. Nut | 8. Pawl | 11. Bolt |
| 2. Washer | 6. Washer | 9. Nut | 12. Brake Pawl Spring |
| 3. Bolt | 7. Bolt | 10. Washer | 13. Pedal Assembly |
| 4. Lever | | | |

Figure 3-17. Brake Pedal Assembly



- | | | | |
|---------------|--------------------------|-------------|--------------------|
| 1. Brake Drum | 4. Spring | 7. Camshaft | 10. Bearing |
| 2. Spring Pin | 5. Spring | 8. Spacer | 11. Mounting Plate |
| 3. Clip | 6. Brake Shoe and Lining | 9. Washer | |

Figure 3-18. Brake Assembly

KEY TO FIGURE 3-19.

- | | | | |
|------------------------|----------------------------|-------------------------|-------------------------------|
| 1. Cover | 21. Drawbar Pivot Fitting | 41. Wheel Spindle | 61. Upper Arm |
| 2. Sleeve | 22. Retaining Ring | 42. Nut | 62. Nut |
| 3. Cable | 23. Drawbar Pivot Pin | 43. Washer | 63. Bolt |
| 4. Lock Spring | 24. Steering Tierod | 44. Bolt | 64. Lower Arm Fitting |
| 5. Ring | 25. Cotter Pin | 45. Retainer | 65. Bushing |
| 6. Pin | 26. Nut | 46. Washer | 66. Insert |
| 7. Towbar Pin | 27. Steering Crank | 47. Ball Stud | 67. Lubrication Fitting |
| 8. Safety Pin | 28. Cotter Pin | 48. Cotter Pin | 68. Lubrication Fitting |
| 9. Sleeve | 29. Nut | 49. Nut | 69. Linear Actuating Cylinder |
| 10. Cable | 30. Screw | 50. Washer | 70. Cotter Pin |
| 11. Tube Assembly | 31. Bolt | 51. Steering Arm | 71. Washer |
| 12. Drawbar Pivot Link | 32. 90° Turn Fitting | 52. Nut | 72. Pin |
| 13. Cotter Pin | 33. Cotter Pin | 53. Washer | 73. Torque Tube |
| 14. Nut | 34. Nut | 54. Bolt | 74. Foot Assembly |
| 15. Washer | 35. Washer | 55. Plug | 75. Quick-Release Pin |
| 16. Bolt | 36. Bolt | 56. Bolt | 76. Cover |
| 17. Nut | 37. Towing Pintle Assembly | 57. Spacer | 77. Sleeve |
| 18. Washer | 38. Nut | 58. Lubrication Fitting | 78. Cable |
| 19. Bolt | 39. Washer | 59. Bushing | 79. Main Frame Assembly |
| 20. Bushing | 40. Bolt | 60. Insert | |






Figure 3-19. Chassis Assembly



- | | | | |
|------------------------|------------------|-----------|-----------------|
| 1. Steering Tierod End | 4. Retainer Ring | 7. Spring | 9. Outboard Rod |
| 2. Lubrication Fitting | 5. Washer | 8. Sleeve | 10. Inboard Rod |
| 3. Check Nut | 6. Retainer Ring | | |

Figure 3-20. Steering Tierod Assembly



- | | | | |
|------------|---------------------|---------------------|-------------------------|
| 1. Bracket | 10. Drain Plug | 19. Screw | 28. Screw |
| 2. Nut | 11. Cap Assembly | 20. RH Side Channel | 29. Lubrication Fitting |
| 3. Washer | 12. Strainer | 21. Nut | 30. Bushing |
| 4. Bolt | 13. Oil Tank | 22. Washer | 31. Bushing |
| 5. Screw | 14. LH Side Channel | 23. Bolt | 32. Fitting |
| 6. Nut | 15. Nut | 24. Bolt | 33. Fwd Tube Assembly |
| 7. Washer | 16. Washer | 25. Screw | 34. Aft Tube Assembly |
| 8. Bolt | 17. Bolt | 26. Nut | |
| 9. Screw | 18. Bolt | 27. Washer | |

Figure 3-21. Main Frame Assembly

DESCRIPTION	FIG & INDEX NO.	MATING PART DESCRIPTION	FIG & INDEX NO.	MAXIMUM CLEARANCE
FITTING, Lower Arm	3-21, 33	PIN, Roller	3-21, 28	0.015 Max
BUSHING, Lower Lift Link	3-21, 30	PIN, Lower Link Pivot	3-21, 28	0.008 Max
BUSHING, Lower Lift Link	3-21, 31	BOLT BOLT	3-21, 29	0.008 Max
BUSHING, Steering Crank	3-19, 27	BOLT	3-21, 29	0.005 Max
BUSHING, Upper Arm Wheel Support	3-19, 59	BOLT, Upper Arm Wheel Support	3-19, 56	0.008 Max
BUSHING, Upper Arm Wheel Support	3-19, 59	SPACER, Upper Arm Wheel Support	3-19, 57	0.008 Max
INSERT, Wheel Arm Upper	3-19, 61	BALL, Wheel Spindle	3-19, 47	0.005 Max
BUSHING, Wheel Arm to Ram Attach	3-19, 65	PIN, Wheel Arm to Ram Attach	3-19, 59	0.010 Max
BUSHING, Main Frame Corner Fitting - Lower	3-19, 64	TUBE, Torque	3-19, 73	0.010 Max
BUSHING, Main Frame Corner Fitting - Lower	3-19, 64	PIN, Upper Arm Wheel	3-19, 72	0.008 Max
BUSHING, Main Frame Corner Fitting - Lower	3-19, 64	SPACER, Upper Arm Wheel Support	3-19, 57	0.008 Max

Figure 3-22. Table of Fits and Clearances

3-34. TEST AFTER ASSEMBLY. (See figures 3-23 and 3-24.)

3-35. Conduct Hydraulic System Tests as follows:

NOTE

LIFT TEST must be conducted on both ends of the trailer.

a. Lift Test. (See figure 3-23.)

1. Adjust trailer rails to a medium level height.
2. Attach chain (8000 lb. min. capacity) to the tie-down hole in one rail at end to be tested, pass chain down and behind the wheel spindle, around the lower spindle and up to the tie down hole in the other rail as shown. Secure a 4 in. x 4 in. spacer approximately 47-3/4 inches long between the rails, close to the chain, to prevent springing of the rails.
3. Apply lift to end being tested in accordance with paragraph 2-6, until lead on pump

handle becomes excessive. If hydraulic cylinders at opposite end do not extend more than 3/8-inch during this test, the trailer may be operated under load at end tested.

4. Repeat test for opposite end of trailer.

NOTE

If hydraulic cylinders extend more than 3/8-inch at end opposite end tested (step 3), the hydraulic system must be bled in accordance with paragraph 2-8.

b. STATIC LOAD TEST. Proceed as follows for testing new trailers.

1. Centrally position trailer to pick up a 16,000 pound load.

NOTE

The load should be centrally located and, if possible, distributed along the trailer rails.

2. Raise rails evenly in accordance with paragraph 2-6 until the full load is on the trailer.
3. Hold the load for two minutes. There shall be no settling of the trailer. If settling occurs, check the following, and correct cause of failure:

- (a) All lines and connections for leakage.
- (b) Faulty pilot check valve - perform "Check Valve Test."

4. A proof load test similar to static load test should be performed after parts replacement or major repairs to the hydraulic system, using an 8,000 pound load.

c. After satisfactory performance of all tests and at no load, raise main frame and rails per paragraph 2-4 and 2-6 to maximum height. The distance from the top of the rails to the floor shall measure 89 inches.

d. Fully lower rails and with the main frame elevated to transportation position, check the hydraulic fluid level in reservoir. Refill necessary to a depth of 3 inches with fluid, Specification MIL-H-5606.

3-36. Winch Ratio Box Load Test. (See figure 3-24.)

- a. Accomplish steps 1 and 2 of "LIFT TEST".
- b. Attach chain (4000 lb. min. capacity) to winch draw-bar (23, figure 2-1) and center of chain




Figure 3-23. Lift Test

between rails, with a dynamometer or similar force measuring device installed between the draw-bar and chain.

- c. Apply load to winch by turning winch drive (18, figure 2-1). Overload clutch must disengage between 2400 and 2700 pounds reading on the force measuring device.

NOTE

If winch ratio box overload clutch disengages at less than 2400 pounds or does not disengage at 2700 pounds maximum, adjust overload clutch in accordance with paragraph 3-31.

- d. Repeat test utilizing the chain installed at opposite end of trailer.

3-37. WINCH RATIO BOX OVERLOAD CLUTCH ADJUSTMENT. (See figure 3-24.)

- a. Cut safety wire (1) and remove with attached lead seal (2).
- b. Remove identification plate (5) by removing 2 screws and lockwashers (3, 4).
- c. Straighten bent prong on washer (6).
- d. Adjust lock-nut (7) to required tension. Turn clockwise to increase tension.
- e. Check for correct overload disengagement per paragraph 3-30.
- f. Bent prong (6) to lock adjust nut (7),
- g. Reassemble identification plate (5) with two screws (3) and lockwashers (4).
- h. Safety wire, using 0.035 dia. corrosion resistant lockwire (MS20995C32-10) and lead seal as shown.




Figure 3-24. Winch Ratio Overload Adjustment